


CFT2200

User Guide





Graphical symbols and supplemental warning marking locations on bottom of terminal.

WARNING

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION

TO PREVENT ELECTRICAL SHOCK, DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE, OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point, within an equilateral triangle, is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

This installation should be made by a qualified service person and should conform to all local codes.


REPAIRS

If you find the unit in need of repair, contact your cable system operator for repair or replacement.

NOTE TO CATV SYSTEM INSTALLER

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close as possible to the point of cable entry as practical.

EXAMPLE OF ANTENNA GROUNDING



NEC=NATIONAL ELECTRICAL CODE

Copyright © 1999 by General Instrument Corporation. All rights reserved. No part of the contents of this book may be reproduced or transmitted in any form or by any means without written permission of the publisher.

The General Instrument logo, STARPHONE and STARVUE are registered trademarks of General Instrument Corporation.

IMPORTANT SAFEGUARDS

1 Read instructions

All the safety and operating instructions should be read before the appliance is operated.

2 Retain instructions

The safety and operating instructions should be retained for future reference.

3 Heed warnings

All warnings on the appliance and in the operating instructions should be adhered to.

4 Follow instructions

All operating and use instructions should be followed.

5 Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

6 Attachments

Do not use attachments not recommended as they may cause hazard.

7 Water and moisture

Do not use this equipment near water; for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like.

8 Accessories

Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall causing serious injury and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the equipment. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

9 Ventilation

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the equipment and to protect it from overheating. The openings should never be blocked by placing the product on a bed, sofa, rug, or similar surface. Equipment should never be placed near or over a radiator or heat register, or in a built-in installation such as a bookcase or rack unless proper ventilation is provided.

10 Power sources

This product should be operated only from the type of power sources indicated on the marking label. If you are not sure of the type of power supplied to your home, consult your local power company. For equipment intended to operate from battery power, or other sources, refer to the operating instructions.

11 Ground or polarization

This equipment may be equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

12 Alternate warnings

This equipment may be equipped with a 3-wire grounding-type plug, a plug having a third (grounding) pin. This pin will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.

13 Power cord protection

Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

14 Outdoor Antenna Grounding

If an outside antenna or cable system is connected to the equipment, be sure the antenna or cable system is grounded as to provide some protection against voltage surges and built-up static charges.

15 Lightning

For added protection for this equipment during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power line surges.

16 Power lines

An outside antenna system should not be located in the vicinity of overhead power lines or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them may be fatal.

17 Overloading

Do not overload wall outlets and extension cords as this can result in a risk of fire or electrical shock.

18 Object and liquid entry

Never push objects of any kind into this equipment through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electrical shock. Never spill liquid of any kind on the product.

19 Servicing

Do not attempt to service this equipment yourself as opening or removing covers may expose you to dangerous voltage or other hazards, refer all servicing to qualified service personnel.

20 Damage requiring service

Unplug this equipment from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a** When the power supply cord or plug is damaged.
- b** If the equipment has been exposed to rain or water.
- c** If liquid has been spilled, or objects have fallen into the equipment.
- d** If the equipment does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the equipment to its normal operation.
- e** If the equipment has been dropped or cabinet has been damaged.
- f** When the equipment exhibits a distinct change in performance, indicating a need for service.

21 Replacement parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

22 Safety check

Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the product is in proper operational condition.

23 Telephone equipment

Observe the following precautions when installing telephone modem equipment:

- a** Never install telephone wiring during a lightning storm.
- b** Never install telephone jacks in a wet location unless the jack is specifically designed for wet locations.
- c** Never touch uninsulated telephone wires or terminals unless the telephone lines have been disconnected at the network interface.
- d** Use caution when installing or modifying telephone lines.

24 Battery usage

Notwithstanding any information provided by GI in this manual regarding the use of batteries, the end user assumes all responsibility and liability to use and dispose of batteries in accordance with all applicable laws, rules and regulations. GI will not be liable to anyone for the end user's failure to use and/or dispose of batteries in the proper manner and in accordance with such laws, rules and regulations, or for any defect contained in batteries which may cause injury damage to persons or property.

CONTENTS

Introduction.....2

Front Panel.....3

Rear Panel5

Recording Your Connections 7

Basic Operation.....8

Turning Power On and Off.....8

Changing Channels.....8

Adjusting the Volume.....9

Disabling the Remote Control..... 10

Restoring the Remote Control..... 10

On-Screen Display 11

Displaying the MAIN MENU 11

Displaying the Program Guide 12

Tuning to a Program..... 13

Channel Status 14

Favorite Channels..... 15

Adding Favorite Channels..... 15

Removing Favorite Channels 16

Passwords17

Adding a Parental Control Password..... 17

Adding a Pay-Per-View Password..... 18

Changing or Deleting Passwords 19

Parental Control20

Setting Control by Channel.....21

Setting Control by Rating22

Setting Control by Time23

Activating Parental Control.....24

Pay-Per-View25

Purchase Control..... 26

Program Recording 27

Timers	29
Setting the Program Timer	29
Adding a Force Tune Timer	30
Adding a Record Timer	31
Edit, Review, or Delete a Timer.....	32
Setting the Sleep Timer	33
Setting the Alarm Timer.....	34
Messages	35

Time Display	36
AC Power Outlet	37
Basic Connections	38
Basic Connections	39
With Audio and Video Baseband Connections	40
With Picture-in-Picture TV	41
The VCR Controller	42

INTRODUCTION


Welcome to General Instrument's CFT2200 set-top terminal, your introduction to unsurpassed audio and video, cable entertainment.

The CFT2200 provides an on-screen display to view, control, and edit program and special features.

To understand your CFT2200, take the time to read this guide and your remote control instructions.

Front Panel

You can turn on the CFT2200, change channels, control volume, and access on-screen menus, using the front-panel buttons or the remote control.




Front Panel

The front panel control keys can be used to operate the CFT2200.

1	DISPLAY	Displays channel or time.
2	MENU	Displays the MAIN MENU on-screen.
3	SELECT	Highlights menu options.
4	ENTER	Accepts choices entered on the menus.
5	VOLUME	Increases or decreases the volume.
6	CHANNEL	Sequentially steps through the channels.
7	INDICATOR	Lights if a message is present.
8	POWER	Turns the CFT2200 on or off.

Rear Panel

The rear panel contains connectors, an ac outlet, and removable panels for installing optional modules with special features.



Rear Panel

The rear panel contains the following connectors and optional features:

1	AC OUTLET	This connector provides an ac outlet to connect the TV.
2	TO TV	This is the basic connection from the CFT2200 to the TV or the VCR.
3	RF IN	This is the connection for cable input from the cable wall outlet.
4	IR	This is the connection for the IR Blaster adapter.
5	L-R	These are the left and right audio connections.
6	VIDEO	This is the connection for video to your TV or VCR.
7	IPPV	This connection is the optional impulse Pay-Per-View feature.


RECORDING YOUR CONNECTIONS



NOTE

Always disconnect the power from the CFT2200 before moving it or changing the cable connections.

Use this diagram to draw your cable connections. This diagram will help you reconnect your system if you move or add new equipment.



Turning Power On and Off

Press **POWER** on the front panel or the remote control to turn the CFT2200 on and off. If you are using a universal remote control, be sure it is set to control the CFT2200.

Changing Channels

Press **CHANNEL** on the front panel or **CHAN** on the remote control to change channels.

Adjusting the Volume


Press **VOLUME** on the front panel or **VOL** on the remote control to adjust the volume. When you adjust the volume, the volume scale is displayed on the screen. To turn the sound off and on, press **MUTE** on the remote control.

The **CFT2200** can be set for the best sound quality on your stereo or TV. When you reach this setting, a small triangle and the message **BEST STEREO** are displayed.



NOTE

To understand your remote control, read the instructions that came with it.



Disabling the Remote Control


You can temporarily disable your remote control to prevent accidentally changing the current programming settings.

To disable the remote control:

- 1** Press MENU on the front panel of the CFT2200 or on the remote control to display the MAIN MENU.
- 2** Select **Control Your Terminal**.
- 3** Select **Deactivate Remote Control**.
- 4** Press SELECT on the remote control. The letters rL0 (remote lockout) display on the front panel.

Restoring the Remote Control

Press any key button on the CFT2200 front panel to restore the remote control.

MAIN MENU		
Control Program Viewing		
Program Guide		
Control Your Terminal		
Messages		
Control Program Timers		
For Help Press *	To Move Press: 	Page 1 of 1



NOTE

The on-screen display is set on a 15-second internal timer. If you do not complete your selection before timing out, you must start again. Read the instructions before beginning.


Displaying the MAIN MENU

The on-screen display offers many options that enhance your television viewing. The easy-to-follow screens enable you to locate information you want quickly and easily. The bottom of each screen provides instructions for making selections.

Before using the on-screen display, read the user guide supplied with your remote control.

Press MENU to display the MAIN MENU. The menu shown is only a sample. The one you see can have different entries in a different order.



GI	FRIDAY, NOV 22	
	3:00p	3:30p
QVC2 11	Holiday Shopping	
TLC 12	Simply Style	A Wedding Story
SHOW 13	Detective Story	
QVC 14	Bracelet Showcase	
TMC 15	The Paint Job	
VISN 16	Courtship of Eddie's Father	Adventures of Black Stallion
For Help Press *	Move: 	2:58pm FRI, NOV 22



Displaying the Program Guide

To display the program guide:

- 1 On the MAIN MENU, select **Program Guide** or press GUIDE on the remote control to display the program guide.
- 2 Follow the instructions on the bottom of the screen to highlight a program. Press INFO to see more information about the program. Press INFO again to return to the program guide.
- 3 Press EXIT to resume regular TV viewing.

TUNE A PROGRAM	
Frequency:	One Time
Start Day:	FRI 2/26
Channel:	45
Start Time:	11:00 pm
To Change Press:  	When Done Press: SELECT

Tuning to a Program


The program guide and force tune timer are used to tune a program.

To tune a program on the program guide:

- 1 Highlight a program or enter a program channel number. The program for the entered channel number is displayed at the top of the program guide.
- 2 Press SELECT. The following conditions will result:
 - If the program you selected is current, the CFT2200 tunes to it immediately.
 - If you selected a program that is scheduled at some future time, the TUNE A PROGRAM screen is displayed and you need to set a program timer. See page 29 for details.
 - If you select a special program (for example, a Pay-Per-View), other screens with information about the program are displayed. See page 25 for details.
 - If the program you select is under parental control, you are prompted to enter your parental control password. See page 17 about parental control passwords.

To scan premium and Pay-Per-View channels on the program guide press FAV, PPV, or MOVIE on the remote control.

To tune a program using a force tune timer, see details on page 30.



NOTE

If you disable automatic display, to access the CHANNEL STATUS screen and Mini-Guide, press INFO on the remote control.

Channel Status

When you change channels, the Channel Status screen is displayed. This screen includes the Mini-Guide and information about special features that have been set for that channel, such as, parental control.

The channel status screen disappears after five seconds, but you can press EXIT or SELECT on the remote control to remove it immediately. You can enable or disable the automatic Channel Status screen.

To set the Channel Status screen:

- 1 Press MENU on the front panel of the CFT2200 or on the remote control to display the MAIN MENU.
- 2 On the MAIN MENU select **Control Your Terminal**.
- 3 Select **Modify Screen Display**.
- 4 Select **Disable Channel Status**.
- 5 Highlight **Enable Channel Status** or **Disable Channel Status**.
- 6 Press SELECT and then press EXIT.

SET FAVORITE CHANNELS			
	2	INFC	3 ABC
	4	NBC	5 WHYY
	6	WPHL	7 WTXF
fav	8	ENN	9 WGBS
fav	10	M2	11 QVC2
	12	TLC	13 SHOW
To set favorite ch press: SELECT		To Clear All Press: 0	

Adding Favorite Channels

You can store your favorite channel numbers for quick and easy access.

To add favorite channels:

- 1 On the MAIN MENU, select **Control Program Viewing**.
- 2 Select **Set Favorite Channels**.
- 3 Highlight the channel you want to add to the favorite channel list, then press SELECT. The fav designation is displayed next to the channel.
- 4 Press EXIT when you are finished.

To scan your favorite channels, press FAV on the remote control. If a channel is defined as a favorite, FAV appears in the channel information display when you tune to it.

Removing Favorite Channels

To remove a favorite channel:

- 1** Highlight the channel you want to remove from the favorite channel list, then press SELECT. The fav designation next to the channel disappears. Press 0 (zero) to remove all favorite channels.
- 2** Press EXIT when you are finished.

GI ENTER PARENTAL CONTROL PASSWORD		
The Parental Control feature requires that you enter a Parental Control Password.		
Remember this number because you will need it in the future to access or change parental controlled viewing.		
---- Use the numeric keypad to enter your password		
When Done Press: SELECT	To Clear Press: 4	To Exit Press: EXIT

GI ACTIVATE PARENTAL CONTROL		
Use the next screen to set your parental control preferences.		
Parental controls will be automatically activated when you leave the setup screen.		
Press SELECT to continue.		
To Return Press: LAST	To Exit Press: EXIT	


The parental control and the Pay-Per-View features enable you to control channel access using a password. You can create a different password for each.

Adding a Parental Control Password

To add a four-digit Parental Control password (for example, 1224):

- 1** On the MAIN MENU, select **Control Program Viewing**.
- 2** Select **Set Parental Control**.
- 3** Select **Control Viewing By Channel, Rating, or Time**.
- 4** Using the numeric keys on the remote control, enter your password on the ENTER PARENTAL CONTROL PASSWORD screen and then press **SELECT**.
- 5** Re-enter the password to confirm it.
- 6** On the ACTIVATE PARENTAL CONTROL screen, press **SELECT**.

If you forget your password, call your cable service provider for assistance.



NOTE


After you set the password, if you enter it incorrectly, you are prompted to try again. If you enter it incorrectly three times in a row, you must wait 15 minutes before trying again.

Adding a Pay-Per-View Password

To add a four-digit Pay-Per-View purchase password (for example, 1228):

- 1** On the MAIN MENU, select **Control Program Viewing**.
- 2** Select **Set Spending Limit**.
- 3** Use the numeric keys on your remote control to enter the password you have chosen and then press SELECT. The SET SPENDING LIMIT screen is displayed.
- 4** Use the numeric keys on your remote control to enter the spending limit. If you set the limit at \$00.00, all purchases require the password. If you set a limit greater than zero, the password is required only if the purchase exceeds the limit.
- 5** Press SELECT.

If you forget your password, call your cable company for assistance.



Changing or Deleting Passwords

You can change your parental control and purchase passwords at any time.

To change a password:

- 1** On the MAIN MENU, select **Control Program Viewing**.
- 2** Select **Change Password**.
- 3** Select the password that you want to change.
- 4** Enter your new password.
- 5** Follow the on-screen instructions to enter the new password or delete your old password by pressing the SELECT key twice.
- 6** Press EXIT when you are finished.



NOTE

Setting parental control by channel number is the most secure method. Parental control by rating or time depends on information sent periodically by your cable service provider, usually about every half-hour. This information is erased by a power failure and parental control is lost until your cable service provider resends the necessary information after power is restored.

If you want to control your children's television viewing, you can use the parental control feature after creating your 4-digit password. You can prevent the CFT2200 from tuning to programming based on channel number, rating, or time of day.

When anyone tries to tune a controlled program, a password prompt is displayed. After you enter the password, all programming is accessible without the password.

To establish parental control:

- 1** Create a four-digit password (See page 17).
- 2** Select the channels, ratings, or time periods that you want to control. See instructions for setting and re-activating parental control on pages 21-24.

CONTROL VIEWING BY CHANNEL			
2	INFC	3	ABC
4	NBC	5	WHYY
6	WPHL	7	WTFX
8	ENN	9	WGDS
10	M2	11	QVC2
12	TLC	13	SHOW
To lock by chan. press: SELECT		To Clear All Press: 0	

Setting Control by Channel

To set parental control by channel:

- 1** On the MAIN MENU, select **Control Program Viewing**.
- 2** Select **Set Parental Control**.
- 3** Select **Control Viewing By Channel**.
- 4** Use the cursor keys to highlight the channel.
- 5** Press SELECT. A lock symbol appears next to the channel.
- 6** To remove control, highlight the channel and then press SELECT. Press 0 (zero) to clear all channels.
- 7** If you want additional control by other methods, press LAST to display the SET PARENTAL CONTROL screen. Press EXIT when you are finished.


CONTROL VIEWING BY RATING CATEGORY	
G	NR
PG	
PG-13	
R	
NC-17	
X	
To lock by rating press: SELECT	To Clear All Press: 0

Setting Control by Rating

Choosing control by rating allows unrestricted viewing of programs below the rating you selected. For example, if you choose R, programs rated PG-13, PG, or G can be viewed without the password; programs rated R, NC-17, or NR require the password.

To set parental control by rating:

- 1 On the MAIN MENU, select **Control Program Viewing**.
- 2 Select **Set Parental Control**.
- 3 On the SET PARENTAL CONTROL screen, select **Control Viewing By Rating**.
- 4 Use the cursor keys to highlight the rating.
- 5 Press SELECT. A lock symbol appears next to the rating and all higher ratings.
- 6 To remove control, highlight the rating and then press SELECT. Press 0 (zero) to clear all ratings.
- 7 If you want additional control by other methods, press LAST to display the SET PARENTAL CONTROL screen. Press EXIT when you are finished.



Setting Control by Time

To set parental control by time:

- 1** On the MAIN MENU, select **Control Program Viewing**.
- 2** Select **Set Parental Control**.
- 3** On the SET PARENTAL CONTROL screen, select **Control Viewing By Time**.
- 4** Set the timer to **ENABLE**.
- 5** Set the control start and stop times.
- 6** Press SELECT.
- 7** To remove control by time, set the timer to DISABLE.
- 8** If you want additional control by other methods, press LAST to display the SET PARENTAL CONTROL screen. Press EXIT when you are finished.

Activating Parental Control

You can view controlled programs by entering your password when prompted. When you do this, all programming is accessible without the password until you re-establish parental control.

To activate parental control:

- 1** On the MAIN MENU select **Control Program Viewing**.
- 2** Select **Activate Parental Control**.
- 3** Press EXIT.

PAY-PER-VIEW

89 CNBC 11:30am - 2:00 pm		
City Slickers		
Three men, feeling like life is closing in on them, decide to escape the stress of the city by joining a two week, modern day cattle drive. -Billy Crystal 1991 Comedy PG13 Critique: **** Price:\$3.00		
For Help press: *	To continue press: INFO	Page 1 of 2

If your cable service provider supports Pay-Per-View purchases through the CFT2200, you can purchase programs from the Program Guide. Special screens display information about the program and help you complete the purchase.

To purchase a program:

- 1** Press SELECT to begin the purchase process.
- 2** Enter your parental control and purchase passwords. Before the purchase is made, you are given the opportunity to confirm or cancel it.

If you selected a current program, the CFT2200 tunes to it. If the program is on at some future time, the CFT2200 sets a timer to tune to it.



NOTE

If you enter your password incorrectly, you are prompted to try again. If you enter it incorrectly three times in a row, you must wait 15 minutes before trying again.

Purchase control enables you to control Pay-Per-View purchases by creating a password and spending limit. Enable purchase control by establishing a purchase password and spending limit. The purchase password is not the same as the parental control password, although you can define them by using the same four digits.

Choose a four-digit purchase password that is easy for you to remember. If you forget your password, call your cable service provider for assistance. See page 18 to create a purchase password and spending limit.

PROGRAM RECORDING



NOTE

While a recording is in progress, the CFT2200 front panel displays REC, and control from front panel buttons and remote control are locked out. To exit the record mode and restore control, press EXIT and then REC on the remote control.

GI		RECORD A PROGRAM	
Frequency:	<input type="text" value="One Time"/>		
Start Day:	<input type="text" value="FRI 2/28"/>		
Channel:	<input type="text" value="45"/>		
Start Time:	<input type="text" value="11:00 pm"/>		
End Time:	<input type="text" value="12:00 am"/>		
To Change Press:	<input type="text" value="⏪"/>	When Done Press:	<input type="text" value="SELECT"/>

The program guide and record timer are used to record programs.

To record a program using the record timer, see page 31.

To record a program using the program guide:

- 1 Put a tape in your VCR.
- 2 On the MAIN MENU, select **Program Guide** or press GUIDE on the remote control.
- 3 Follow the directions on the bottom of the screen to highlight the program that you want to record.
- 4 Press REC on the remote control.
- 5 Select **One Time, Daily, Weekly, Weekdays**, or **Weekends** on the RECORD A PROGRAM screen.
- 6 Press SELECT. You will have a chance to review your settings before confirming them.

- 7** Program your VCR to turn on at the same time and tune to the same channel that you set on the RECORD A PROGRAM screen. The CFT2200 and the VCR must be programmed separately for each scheduled recording.
- If the program you select is under parental control, you are prompted to enter your parental control password.
 - If you select a Pay-Per-View program, you are prompted to complete the purchase process.
 - If you set a timer that conflicts with one you set earlier, you are prompted to select one. Follow the on-screen instructions.


GT		TUNE A PROGRAM	
Frequency:	<input type="text" value="One Time"/>		
Start Day:	<input type="text" value="FRI 2/26"/>		
Channel:	<input type="text" value="45"/>		
Start Time:	<input type="text" value="11:00 pm"/>		
To Change Press: <input type="button" value="⏮"/>	<input type="text"/>	When Done Press: <input type="button" value="SELECT"/>	<input type="text"/>



Setting the Program Timer

The TUNE A PROGRAM screen is displayed when you try to tune a program playing in the future.

To set the timer:

- 1** Select **One-Time, Daily, Weekly, Weekdays,** or **Weekends.**
- 2** Press SELECT and then EXIT. The area around the program in the program guide turns dark blue to indicate that a timer is set. The CFT2200 automatically tunes to the program at its start time.

GT MAIN MENU		
Control Program Viewing		
Program Guide		
Control Your Terminal		
Messages		
Control Program Timers		
For Help Press *	To Move Press: 	Page 1 of 1



GT ADD FORCE TUNE TIMER		
Frequency:	<input type="text" value="One Time"/>	
Start Day:	<input type="text" value="FRI 2/28"/>	
Channel:	<input type="text" value="45"/>	
Start Time:	<input type="text" value="11:00 pm"/>	
To Change Press: 	To Move Press: 	When Done Press: SELECT

Adding a Force Tune Timer

A Force Tune Timer is used to tune a program at the desired time.

To add a Force Tune Timer:

- 1** On the MAIN MENU, select **Control Program Timers**.
- 2** Select **Add Force Tune Timer**.
- 3** Follow the instructions on the bottom of the screen to make your selections and then press SELECT. If you set a timer that conflicts with one you set earlier, you are prompted to select one.
- 4** Confirm your selection and then press SELECT on your remote control.

GT ADD RECORD TIMER		
Frequency:	One Time	
Start Day:	FRI 2/26	
Channel:	45	
Start Time:	11:00 pm	
End Time:	12:00 am	
To Change Press: 	To Move Press: 	When Done Press: SELECT

Adding a Record Timer

A Record Timer is used to record a program at a desired time.


To add a Record Timer:

- 1 On the MAIN MENU, select **Control Program Timers**.
- 2 Select **Add Record Timer**.
- 3 Follow the instructions on the bottom of the screen to make your selections and then press SELECT. If you set a timer that conflicts with one you set earlier, you are prompted to select which one to keep.
- 4 Confirm your selection and then press SELECT on your remote control.

Edit, Review, or Delete a Timer

To edit, review, or delete timers use the EDIT PROGRAM TIMERS screen:

- 1** On the MAIN MENU, select **Control Program Timers**.
- 2** Select **Edit Program Timers**.
- 3** Select a timer to edit, review, or delete.
- 4** Follow the instructions on the bottom of the screen to make your selections and then press SELECT.
- 5** Confirm your selection and then press SELECT on your remote control.






Setting the Sleep Timer

You can set the CFT2200 to turn itself and your TV off after a certain period of time. Your TV must be plugged into the ac outlet in the rear of the CFT2200 and the outlet must be set to switch on and off with the CFT2200. See page 37 to set the ac outlet.

To set the sleep timer:

- 1** On the MAIN MENU, select **Control Your Terminal**.
- 2** Select **Set Sleep Timer**.
- 3** Set the time.
- 4** Press SELECT and then press EXIT.

GT SET ALARM TIMERS		
Daily Turn On:	Enabled	
Set Time:	12:00 am	
Daily Turn Off:	Enabled	
Set Time:	5:00 am	
To Change Press:	To Move Press:	When Done Press:
	 	SELECT


Setting the Alarm Timer

You can set alarm timers to turn the CFT2200 and your TV on and off at certain times. Your TV must be plugged into the ac outlet on the rear of the CFT2200 and the outlet must be set to switch on and off with the CFT2200. See page 37 to set the ac outlet.

To set the alarm timers:

- 1** On the MAIN MENU, select **Control Your Terminal**.
- 2** Select **Set Alarm Timers**.
- 3** Set Daily Turn On and Daily Turn Off to Enabled.
- 4** Set the on and off times. Momentarily pressing the left and right cursor keys changes the time by one minute. Press and hold the cursor keys to change the time in 15-minute increments.
- 5** Press SELECT and then press EXIT.

MESSAGES


MESSAGES		
New services		
Lineup change		
Movie special		
To read Press: SELECT	To Move Press: 	Page 1 of 1

Occasionally, your cable service provider might send you messages about new service offerings, special promotions, or other information. The MESSAGES indicator is displayed on the CFT2200 front panel until you read the messages displayed.

To read the messages:

- 1 On the MAIN MENU, select **Messages**.
- 2 Select a message from the list.
- 3 After reading the message, you have the option to save it. While you can delete most of the messages, some can only be deleted by your service provider.
- 4 Press EXIT when you are finished.

TIME DISPLAY



The front panel of the CFT2200 normally displays the selected channel number but you can display the time. When you change channels, the new channel is momentarily displayed. When you turn the terminal off, it continues to display the time.

To display the time:


- 1** On the MAIN MENU, select **Control Your Terminal**.
- 2** Select **Set Up Your System**.
- 3** Select **Display Time On Your Terminal**.
- 4** Highlight **Enable** and then press SELECT.
- 5** Press EXIT.

AC POWER OUTLET



NOTE

Some TV sets require the power to always remain on. Check the user handbook for your TV.



You can plug your TV into the ac connector on the rear of the CFT2200. This enables you to turn your TV on and off with the CFT2200. The default setting for the outlet is switched (that is, it turns on and off with the CFT2200).

To set the ac power outlet to unswitched:

- 1 On the MAIN MENU, select **Control Your Terminal**.
- 2 Select **Set Up Your System**.
- 3 Select **Set AC Power Outlet**.
- 4 Highlight the unswitched option.
- 5 Press SELECT and then press EXIT.


You may want to add a VCR or your stereo system.

To add equipment, you need the correct cables:

- For most connections, use 75-ohm coaxial cable equipped with F-type connectors.
- To use the audio or video outputs from the CFT2200, use cables equipped with RCA-type connectors.


The following diagram illustrates the basic connection to view cable programming. With an optional VCR, you can record programming. You can record and listen to stereo programming if you have a stereo TV or stereo VCR.

Basic Connections




With Audio and Video Baseband Connections

The following diagram illustrates how to hookup to a TV having optional audio and video baseband connections.




With Picture-in-Picture TV

If your TV offers this feature, the following diagram illustrates how to enable Picture-in-Picture. You can only tune non-scrambled channels on the B input.




THE VCR CONTROLLER

Some cable service providers offer the option of infrared VCR control. If your CFT2200 is equipped with the VCR controller option, an IR transmitter is plugged into the rear of the CFT2200 and mounted to the front of your VCR. The CFT2200 can then turn the VCR on to record a selected program and turn it off when the program is over.



THE VCR CONTROLLER



If you have the VCR controller option, your cable service provider will usually set it up during the installation of the CFT2200.

If you need to set up the VCR controller:

- 1** On the MAIN MENU select **Control Your Terminal**.
- 2** Select **Set Up Your System**.
- 3** Select **Set Up VCR Controller**.
- 4** Follow the on-screen directions. You will be prompted for the manufacturer of your VCR and to check for the proper VCR controller response.
- 5** Press EXIT when you are finished.

General Instrument Corporation
466340-001-99
7/99